

X-RAY TOMOGRAPHY FOR ADVANCEMENT OF LASER POWDER BED FUSION ADDITIVE MANUFACTURING

ANTON DU PLESSIS

ASSOCIATE PROFESSOR, STELLENBOSCH UNIVERSITY, SOUTH AFRICA

13 Sept 2019

TOSCA2019, Southampton, UK



Research group
3D INNOVATION



CT FACILITY
STELLENBOSCH

Background

- 2-time Tosca presenter
- Manager of Stellenbosch CT facility
- Editorial board of journals
 - Additive Manufacturing
 - Scientific African
 - Gigabyte (new data journal)



(GIGA)byte

Publishing at the Speed of Research

Publish your microCT models with *GigaByte*

- New “updatable” data journal coming in 2020 from *GigaScience*
- Get credit for peer reviewed datasets
- Includes integrated data hosting in GigaDB repository
- Curation and integration of models in sketchfab


<http://gigabytejournal.com/>

Outline

- Additive manufacturing
- X-ray CT for additive manufacturing
- Standardization in CT for AM: round robin test 1
- CT round robin test 2
- Image quality quantification
- Conclusions and future of CT in AM

Additive manufacturing

- Additive manufacturing (AM) / 3D printing has grown over the last decade, way past the original “prototyping” use
- Today it is possible (and proven) to manufacture mission-critical parts
- Various materials are possible, the most well studied metals for AM are Ti6Al4V, AlSi10Mg, and various steels
- Laser powder bed fusion is the most widely used and best developed AM method, with the highest complexity possible in produced parts



From: DebRoy, T., et al. 2018. Additive manufacturing of metallic components—process, structure and properties. *Progress in Materials Science*, 92, pp.112-224.

X-ray tomography for additive manufacturing


→ Widely known already for non-destructive and quantitative analysis of AM parts for:

- Porosity
- Dimensional measurement

→ Other newer uses are:


- Analysis of powder feedstock for quality – size, shape and porosity
- Density
- Time-lapse or 4D CT
- Surface roughness/topography
- Simulations – FEM
- Multiscale CT, etc.

* X-ray microcomputed tomography in additive manufacturing: a review of the current technology and applications. *3D Printing and Additive Manufacturing*, 5(3), pp.227-247. Du Plessis, A., Yadroitsev, I., Yadroitsava, I. and Le Roux, S.G., 2018. <https://www.liebertpub.com/doi/full/10.1089/3dp.2018.0060>



* du Plessis, A. and le Roux, S.G., 2018. Standardized X-ray tomography testing of additively manufactured parts: A round robin test. *Additive Manufacturing*, 24, pp.125-136.

<https://doi.org/10.1016/j.addma.2018.09.014>




0.13%


* du Plessis, A. and le Roux, S.G., 2018. Standardized X-ray tomography testing of additively manufactured parts: A round robin test. *Additive Manufacturing*, 24, pp.125-136.

<https://doi.org/10.1016/j.addma.2018.09.014>


Diameter [mm]



2 mm





Volume [mm³]





2.5 mm









Volume [mm³]

0.02870

0.02592

0.02313

0.02034

0.01755

0.01476

0.01197

0.00919


0.00640

0.00361

0.00082



10 mm



ROUND ROBIN TEST 1

- **PARTS PRODUCED IN VARIETY OF L-PBF SYSTEMS – ATTEMPT TO MAKE GOOD PARTS: CUBE, BRACKET + CYLINDER**
- **ALL PARTS SCANNED ACCORDING TO STANDARD/PRESCRIBED PARAMETERS AND IMAGE ANALYSIS STEPS**
- **DEMONSTRATED TWO THINGS**
 1. **VARIOUS DISTINCT ERROR TYPES ARE PRESENT EVEN IN PARTS WITH >99.87% DENSITY**
 2. **ALL THESE ERRORS CAN BE CLEARLY IDENTIFIED USING THE STANDARD “RECIPE”**

ROUND ROBIN TEST 2

- **ONE SET OF BRACKET, CUBE AND CYLINDER WAS SELECTED FROM PREVIOUS WORK WITH DIFFERENT PORE TYPES**
- **SENT TO TOTAL OF 10 DIFFERENT MICRO-CT LABS, AND ASKED TO ANALYSE ACCORDING TO THE “RECIPE”**
- **WHAT WAS LEARNED**
 - **MAJOR POROSITY DISTRIBUTIONS CORRECTLY IDENTIFIED BY ALL**
 - **QUANTIFICATION WAS OK BUT NOT PERFECT**
 - **IMAGE ANALYSIS WORKFLOW REQUIRES SOME SIMPLIFICATIONS**
 - **IMAGE QUALITY VARIES IN DIFFERENT SCANS – AFFECTING THE WORKFLOW**

* du Plessis, A. et al 2019. Laboratory X-ray tomography for metal additive manufacturing: round robin test. *Additive Manufacturing*, accepted for publication. <https://doi.org/10.1016/j.addma.2019.100837>

IMAGE QUALITY QUANTIFICATION

- **THE 10 MM CUBE WAS USED AGAIN AND SCANNED ON DIFFERENT SYSTEMS, WITH VARIED SCAN PARAMETERS INDUCING DIFFERENT ARTIFACTS**
- **IMAGE QUALITY WAS QUANTIFIED ACCORDING TO A SIMPLE METHOD:**

- $$Q = \frac{|\mu_2 - \mu_1|}{\sqrt{\sigma_1^2 + \sigma_2^2}}$$





IMAGE QUALITY QUANTIFICATION



Q1

Q2

<https://www.researchgate.net/publication/335842062> Not all scans are equal X-ray tomography image quality measurement

IMAGE QUALITY QUANTIFICATION – SCAN TIME




IMAGE QUALITY QUANTIFICATION – SCAN TIME




IMAGE QUALITY QUANTIFICATION – SCAN TIME





IMAGE QUALITY QUANTIFICATION – SCAN TIME



CONCLUSIONS

- **AN OVERVIEW WAS GIVEN OF TOMOGRAPHY FOR SCIENTIFIC ADVANCEMENT IN THE FIELD OF METAL ADDITIVE MANUFACTURING**
- **HUGE POTENTIAL TO IMPROVE ADDITIVE PROCESSES AND ASSIST IN QUALIFICATION OF PARTS FOR HIGH END APPLICATIONS**
- **IMAGE QUALITY QUANTIFICATION IS NOW POSSIBLE IN CT SCANS (NOT ONLY FOR AM CUBES)**

CONTACT

- **FOR MY RESEARCH & PUBLICATIONS:**
 - [BLOGS.SUN.AC.ZA/DUPLESSIS](https://blogs.sun.ac.za/duplessis)
 - EMAIL ANTON2@SUN.AC.ZA
 - PLEASE CONNECT WITH ME ON RESEARCHGATE, LINKEDIN AND TWITTER
 - FACILITY: WWW.SUN.AC.ZA/CTSCANNER

ACKNOWLEDGEMENT FOR ALL COLLABORATORS, ESPECIALLY:

PROF IGOR YADROITSEV

DR INA YADROITSAVA

THANKS FOR LISTENING!



SOUTH AFRICAN CONNECTIONS

VENO NAIDOO, CURRENTLY AT ZEISS UK